# **Dylan**Task Chair

Set Up - User Guide

Helping you sit smarter — for the important comfort and effective support you require.





# Seat Height

The front right lever operates the gas lift to adjust the seat height. To lower the chair, **push the lever down**. To raise it, push the lever down while lifting your weight off the seat.



# 2 Back Height

The **backrest height** is adjustable by placing your fingers under the backrest and lifting. The back is on a ratchet and will automatically drop down when the highest point is reached.



### 3 Back Adjustment

Push the front left lever to activate the **back rake adjustment** use your body weight to adjust and push the lever down to lock into place.



## 4 Seat Depth

The lever at the front left, operates the **seat depth adjustment**. Lift the lever up while sliding the seat forward and down to lock in position.



#### 5 Lumbar Support

Adjustable lumbar is located at the back of the chair, simply lift up and down to adjust.



#### 6 Arm Adjustment

Adjust the **height adjustable arms** by the button on the outside of the arm. Push the button in to lift the arm and release the button to lock in position. Simply slide the arms back and forth to **adjust the depth**. To assist easy exit from the chair, **twist arms pads**.